# PROCHOICE P2 FLAT FOLD DISPOSABLE RESPIRATOR

PRODUCT CODE: PCFFP2V





# FEATURES AND BENEFITS

P2 Rating for protection against mechanically and thermally generated particles

Exhalation valve for extra comfort

Contoured shape for enhanced fit, seal & comfort

Easily worn with glasses & goggles

Durable & lightweight

Adjustable dual head strap for optimum fit

Mouldable high density foam nose piece for a secure & comfortable seal

Fits most common face shapes

Latex free strap

Staple free



## **APPLICATIONS**

These respirators may be suitable for the following suggested applications (but are not limited to): Class P1: Sanding, Grinding, Cutting, Drilling, Sawing, Plastering, Rendering, Excavation, Powders or Dusts

Class P2 (as for P1 above, plus): Light Welding, Soldering, Foundry Operations, Aerosols, Diesel Particulate Materials



# **HOW TO CORRECTLY FIT A DISPOSABLE MASK**

PRODUCT CODE: PCFFP2V





Latex-free, adjustable elastic band Straps

Polypropylene melt-blown Filter

Weight 15g each Qty/Box 10 masks 20 boxes Qty/Carton:



Hold respirator in hand with moulded nose contour (narrow end) at fingertips. Allow head-straps to hang below hand.



Place respirator against Place the top strap high your face.



AS/NZS 1716 BMP No 547903

Standards

on the back of your head. Move the bottom strap over your head and position it below your ears.



### STORAGE AND TRANSPORTATION

Shelf life of the unopened product is three (3) years from the date of manufacture when stored within temperature range of -20°C to +25°C and at less than 80% relative humidity.

End of shelf life date is marked on the product packaging. Before initial use, always check that the product is within the stated shelf life. When storing or transporting this product use original packaging provided



Use both hands to cup the respirator to the shape of your nose and face for a secure. comfortable fit



Test the fit. Cup both hands over the respirator and exhale strongly. If airflows around your nose, tighten the nose-piece. If air escapes around the edges, reposition the straps for a better fit.



### **WARNINGS AND USE LIMITATIONS**

ProChoice Particulate Respirator PCFFP2V Always ensure the complete product is:

- Suitable for the application;
- Fitted correctly;
- Worn during all periods of exposure
- Replaced when necessary



# STANDARDS

AS NZS 1716-2012 Respiratory protective devices: P2 rating. To be used in conjunction with: AS NZS 1715-2009 Selection use and maintenance of respiratory protective equipment

#### WΑ

# T (618) 9301 7888

E wa@paramountsafety.com.au

#### **MELBOURNE**

T [613] 9764 9900 F [613] 9764 9800 E vic@paramountsafety.com.au

T (612) 9601 3877

E nsw@paramountsafety.com.au

T (617) 3806 2699 (617) 3806 3266 E gld@paramountsafety.com.au

#### **ADELAIDE**

M 0424 504 802

T [613] 9764 9900 F [613] 9764 9800 E sa@paramountsafety.com.au

#### **NEW ZEALAND**

T (649) 525 8090

E nz@paramountsafety.co.nz